

# **XBOX SKIN APPLICATION INSTRUCTIONS**

**Installers must fully read and understand the below instructions before starting installation of decal sets onto customers or your own hardware.**

***You will need :***

½ cup of water

2-3 drops of dish washing liquid

Plastic squeegee or credit card and piece of cloth

Something to clean your Xbox with (meths recommended)

1. Ensure X-Box is completely clean and free of grease, dust or any other foreign objects or residues. (in our modification shop we use meths to be 100% sure)
2. In a bowl or plate mix up about half a cup of water and 1 or 2 drops of dish washing liquid or soap.
3. Use a clean rag or towel to apply the soapy solution to the front / top of the Xbox, ensure its just damp and not dripping into the insides. (be very careful)
4. Remove one of the front decals from the sheet line up and apply to the front of Xbox. (do this carefully being careful not to rip the decal)
5. The soapy solution you applied earlier will allow you to move the decal around or remove and re-position to get it lined up to your satisfaction. Take care not to rip the decal in the corners if lifting to reposition.
6. Once decal is lined up use a squeegee or credit card to work any air trapped under the skin out to the edges, work from the center out, working any bubbles or creases carefully out to the edges. Make sure you press firmly to make sure the contact adhesive used for the skins works properly and any excess water worked to the outside and out from underneath the skin.
7. Any tiny bubbles left caused from not working air out form the center to the edges correctly should dissipate once your Xbox gets hot a couple of times form use.